



BELT BREAK-IN PROCEDURE



**WASH THE BELT IN WARM SOAPY WATER AND
LET IT AIR DRY TO REMOVE ALL RESIDUE.**



**SCUFF DRIVE AND DRIVEN CLUTCH SHEAVES
WITH A SCOTCH-BRITE PAD**



**CLEAN WITH BRAKE/CONTACT CLEANER AND
A CLEAN TOWEL**



**DRIVE UNIT IN LOW GEAR FOR THE FIRST
15 MILES. VARYING YOUR SPEED. AVOID
RIDING AT WIDE OPEN THROTTLE DURING
THIS TIME. THIS WILL ENSURE THE BELT
GETS SEATED PROPERLY.**

**CALL OR EMAIL US WITH ANY QUESTIONS
218-454-4584 / SALES@GBOOSTTECHNOLOGY.COM**